

CRADLE INTERFACE



USB-COM



USB



RS232

COUNTRY KEYBOARD TYPES



US



Italy



Germany



Spain



France



Russia



UK



Ukraine



Danish



Turkey

CONVERT CASE



No Case
Conversion



Convert All to
Upper Case



Convert All to
Lower Case



THE CE MARK AFFIXED TO THE PRODUCT CERTIFY THAT THE PRODUCT SATISFIES THE BASIC SAFETY REQUIREMENTS.

The device is in conformity with the essential Electromagnetic Compatibility and Electric Safety requirements laid down in Directives 2014/30/EU and 2014/35/EU.

The device is in conformity with the essential requirements laid down in Directives 2014/53/EU about devices equipped with intentional radiators.

The Declaration of Conformity and other available certifications can be downloaded from the site www.custom4u.it.



GUIDELINES FOR THE DISPOSAL OF THE PRODUCT

The crossed-out rubbish bin logo means that used electrical and electronic products shall NOT be mixed with unsorted municipal waste. For more detailed information about recycling of this product, refer to the instructions of your country for the disposal of these products.

- Do not dispose of this equipment as miscellaneous solid municipal waste, but arrange to have it collected separately.
- The re-use or correct recycling of the electronic and electrical equipment (EEE) is important in order to protect the environment and the wellbeing of humans.
- In accordance with European Directive WEEE 2002/96/EC, special collection points are available to which to deliver waste electrical and electronic equipment and the equipment can also be handed over to a distributor at the moment of purchasing a new equivalent type.
- The public administration and producers of electrical and electronic equipment are involved in facilitating the processes of the re-use and recovery of waste electrical and electronic equipment through the organisation of collection activities and the use of appropriate planning arrangements.
- Unauthorised disposal of waste electrical and electronic equipment is punishable by law with the appropriate penalties.

CUSTOM S.p.A.
Via Berettine 2/B
43010 Fontevivo (PARMA) - Italy
Tel. : +39 0521-680111
Fax : +39 0521-610701
[http: www.custom.biz](http://www.custom.biz)

Customer Service Department:
www.custom4u.it

© 2021 CUSTOM S.p.A. – Italy.
All rights reserved. Total or partial reproduction of this manual in whatever form, whether by printed or electronic means, is forbidden. While guaranteeing that the information contained in it has been carefully checked, CUSTOM S.p.A. and other entities utilized in the realization of this manual bear no responsibility for how the manual is used. Information regarding any errors found in it or suggestions on how it could be improved are appreciated. Since products are subject to continuous check and improvement, CUSTOM S.p.A. reserves the right to make changes in information contained in this manual without prior notification.

Other company and product names mentioned herein may be trademarks of their respective companies. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. CUSTOM S.p.A. assumes no responsibility with regard to the performance or use of these products.

GENERAL INSTRUCTIONS

CUSTOM S.p.A. declines all responsibility for accidents or damage to persons or property occurring as a result of tampering, structural or functional modifications, unsuitable or incorrect installations, environments not in keeping with the equipment's protection degree or with the required temperature and humidity conditions, failure to carry out maintenance and periodical inspections and poor repair work.

This document provides a description of the main features of the device. For a detailed description of all functions such as maintenance and cleaning please refer to the user manual available on www.custom4u.it.

The images used in this manual are used as an illustrative examples. They couldn't reproduce the described model faithfully.

Unless otherwise specified, the information given in this manual are referred to all models in production at the issue date of this document.

GENERAL SAFETY INFORMATION

Your attention is drawn to the following actions that could compromise the characteristics of the product:

- Read and retain the instructions which follow.
- Follow all indications and instructions given on the device.
- Make sure that the surface on which the device rests is stable. If it is not, the device could fall, seriously damaging it.
- Do not fix indissolubly the device or its accessories such as power supplies unless specifically provided in this manual.
- When positioning the device, make sure cables do not get damaged.
- Before any type of work is done on the machine, disconnect the power supply.
- Take care the operating temperature range of equipment and its ancillary components.
- Do not block the ventilation openings.
- Do not insert objects inside the device as this could cause short-circuiting or damage components that could jeopardize printer functioning.
- Do not carry out repairs on the device yourself, except for the normal maintenance operations given in the user manual.
- The equipment must be accessible on these components only to trained, authorized personnel.
- Periodically perform scheduled maintenance on the device to avoid dirt build-up that could compromise the correct, safe operation of the unit.
- Do not look directly into LED beam or reflected led beam from a mirrored surface, it may cause pain.
- Unplug or turn off the device be sure to stop the led beam before cleaning the portion of the device where LED light is generated and received (emitter/receiver). Otherwise, exposure may cause pain.

SHORT GUIDE

SR300NM SR300NM-CR

CUSTOM®

CUSTOM S.p.A.
World Headquarters
Via Berettine, 2/B - 43010 Fontevivo, Parma ITALY
Tel. +39 0521 680111 - Fax +39 0521 610701
info@custom.biz - www.custom.biz

All rights reserved

www.custom.biz

Part Number : 7820000002300 Rev. 1.20

CUSTOM®

CRADLE PAIRING

1. Disconnect the cradle from your computer.

2. Bluetooth SPP mode.



3. Cradle pairing mode.



4. Connect the cradle to your computer.

5. Pairing mode.



After successfully pairing, the scanner will beep and the LED will turn blue and stop flashing.

MOBILE DEVIDE PAIRING

To pair the scanner with an iOS or Android mobile device, use the barcodes below. When paired with an iOS device, quickly double press the trigger to toggle the on-screen keyboard.

If you have previously paired this scanner with this device, navigate to the Bluetooth setting and 'forget' for the scanner; before attempting to pair again.

1. Clear previous pair.



2. HID mode.



3. Pairing mode.



4. Open the Bluetooth setting on your device and connect to the "Bluetooth Scanner".

After successfully pairing, the scanner will beep and the LED will turn blue and stop flashing.

SCANNER LEDS AND BEEP CODES

BLUE	Quickly flashing	Pairing Mode
BLUE	Slowly flashing	Disconnected
RED and BLUE	On	Power On connected Ready to Scan
Repeated beeping		Low Battery
GREEN	On	Charging
ORANGE	Blinks x1 1 beep	Low Battery
ORANGE	Blinks x2 2 beep	Successful Scan in Memory Mode
ORANGE	Blinks x4 4 beep	Out of Scan Range

CRADLE LEDS

BLUE	Quickly flashing	Pairing Mode
BLUE	Slowly flashing	Disconnected
BLUE	On	Scanner Connected
RED	On	Power On
GREEN	On	Charging

CHANGE BLUETOOTH SCANNER NAME

To make command barcode and scan it.
%%BT_NAME=ADCB
"ADCB" is replaced part with customized name.

ON-SCREEN KEYBOARD INPUT



iOS keyboard On/Off

Togge between barcode scanning and on-screen keyboard input to work with iOS devices.



Enable iOS Hot Key

After enable iOS hot key, you may simply press trigger once to toggle the iOS devices on-screen keyboard.

AUTO RECONNECT OPTION



5 minutes



1 minute



10 minutes



*20 minutes

VIBRATION SETTING



Enable



*Disable

SLEEP SETTING

The sleep setting barcodes configure how long the scanner can be idle before powering off.



2 minutes



*5 minutes



10 minutes



20 minutes



Never



Power Off

MEMORY MODE

While in memory mode, the scanner will store all barcodes scanned until the "Transmit Stored Data" barcode is scanned.



Enter Memory Mode



Transmit Stored Data



Transmit Count of
Stored Barcodes



Clear All Stored Data



Exit Memory Mode